




**A/C** UNIVERSAL REMOTE CONTROL  
**BRAND-SHORTCUT**  
 User Manual  
**RW-A799K**

Welcome to use this remote control ! In order to use this product well, please read this manual carefully. This instruction should be kept in good condition and in a safe place so that you may use it again next time.

**Product characteristics**


- Fully compatible with various brand of air conditioner internal and external.
- No need set up, can use it directly for most brands of air conditioner.
- Direct fast searching for brand shortcut and one key auto-searching, set in easy and fast.
- Initiating temperature lock function, convenient to lock temp. and 'energy save'setting
- Time setting and timer power on/off functions.
- Kids-lock function avoid losing the code which have been set up.
- Large LCD display with brand show, convenient to operate.
- Dormant LCD display to extent the battery's life.
- Power-off memory, no losing code during changing battery.

**Panel description**



**Battery installation**

Open the cover and insert two size AAA alkalinescent batteries (not included) according to the marks ⊕ ⊖ in the battery compartment.




Set Ways for your choice as below:


- **Fast Searching mode for brand shortcut;**
- **One key fast searching;**
- **Manual input code searching;**

**Fast searching mode for brand shortcut:**


**1** Connect the power of air conditioner, then aim the remote at the receiver window of the air conditioner.



**2** Keep pressing brand choose '+' or '-' key for 6 seconds and then a ◀ arrow to the brand will flash in the LCD; Press the key of '+' or '-' to choose one brand you need which showed on the LCD. Such as 'DAIKIN' ◀




**3** After choosing the brand keep pressing the SET key (SET) for searching and unlash it immediately once heard a voice of as 'Dii' from air conditioner and air conditioner turn on/off.



**4** Check other buttons ( except 'SET', 'TEMPERATURE +', 'TEMPERATURE -', Brand choose '+' '-' key) whether they can work or not. If they all can work, it means setting successfully. Finally press SET key (SET) for exit. If not workable, please repeat step 2 and step 3 until the setting to be finished successfully.


Note: Once finished setting and chosen brand please do not press choose '+' '-' key when the arrow is still flashing; After about 10 seconds it will automatically exit from the mode of brand choosing.




In case that your air conditioner brands is not included in our brand list showed, please search as following two ways:

**One key fast searching:**


**1** Connect the power of air conditioner, then aim the remote at the receiver window of the air conditioner.




**2** Keep pressing Set key (SET) for about 3 seconds, then brand code on the bottom of LCD screen begin to change, it means the quick search is going.



**3** Pay attention to your air conditioner and release the SET key (SET) immediately once heard a voice of as 'Dii' and air conditioner turn on/off.




**4** Check other keys ( except 'SET', 'TEMPERATURE +', 'TEMPERATURE -', Brand choose '+' '-' key) whether they can work or not. If they all can work, it means setting successfully. Finally press SET key (SET) for exit. If not workable, please repeat step 2 and step 3 until the setting to be finished successfully.




**Manual input code searching:**


**1** Connect power of air conditioner, find the code for your brand from CODE LIST, Such as: DAIKIN 740-759



**2** Then aim the remote at the receiver window of the air conditioner. Keep pressing Set key (SET) for about 3 seconds, then brand code on the bottom of LCD screen begin to flash and change, repeat press the key of 'Temperature +' (TEMP+) or 'Temperature -' (TEMP-) to search until you get the code for your air conditioner brand.



**3** Pay attention to your air conditioner and release immediately the key of 'Temperature +' (TEMP+) or 'Temperature -' (TEMP-) once heard a voice of as 'Dii' and air conditioner turn on/off.



**4** Check other keys (except 'SET', 'TEMPERATURE +', 'TEMPERATURE -', Brand choose '+' '-' key) whether they can work or not. If they all can work, it means setting successfully. Finally press the SET key (SET) for exit. If not workable, please repeat step 2 and step 3 until the setting to be finished successfully.

